

Information Menu

- [Information] - Main - Advanced - Security - Boot - Exit -

```

CPU Type               Intel(R) Celeron(R) CPU X 3038
CPU Speed              3000 MHz
System Memory:         300 KB
Extended Memory:       300000 KB
HDDL Serial Number     xxxxxxxxxxxxxx
HDDR Serial Number     None
System BIOS Version    R01-xx
VGA BIOS Version       x. xx. xx
KBC Version            xx. xx. xx
Serial Number          xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx
Asset Tag Number
Product Name           FLORA 270W/NK1
Manufacture Name       H TACH
ULI D Number           xxxxxxxxxxxx-xxxx-xxxx-xxxx-xxxxxxxxxxxxxxxx
LAN Device             Ex1st ( MAC Address = xx:xx:xx:xx:xx:xx)

```

[Information Menu](#)

BIOS item	BIOS default	BIOS value
CPU Type		Intel(R) Celeron(R) CPU XXXGHz
CPU Speed		XXXX MHz
System Memory		XXX KB
Extended Memory		XXXXXX KB
HDD1 Serial Number		XXXXXXXXXX
HDD2 Serial Number		None
System BIOS Version		R01- XX
VGA BIOS Version		X.XX.XX
KBC Version		XXXXXX
Serial Number		XXXXXXXXXXXXXXXXXXXXXXXXXXXX
Asset Tag Number		
Product Name		FLORA 270WNK1
Manufacture Name		HITACHI
UUID Number		XXXXXXXX-XXXX-XXXX-XXXX-XXXXXXXXXXXX
LAN Device		Exist (MAC Address =XXXXXXXXXXXXXX)

```

CPU Type  CPU  0 0 0 0 0 0 0 0
CPU Speed  CPU  0 0 0 0 0 0 0 0
System Memory  0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Extended Memory  0 0 0 0 0 0 0 0 0 0 0 0 0
HDD1: Serial Number  HDD1  0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
HDD2: Serial Number  HDD2  0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
System BIOS Version  BIOS  0 0 0 0 0 0 0 0 0 0 0 0
VGA BIOS Version  VGA BIOS  0 0 0 0 0 0 0 0 0 0 0 0
KBC Version  KBC BIOS  0 0 0 0 0 0 0 0 0 0 0 0
Serial Number  0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Asset Tag Number  Asset Tag  0 0 0 0 0 0 0 0 0 0 0 0
Product Name  0 0 0 0 0 0 0 0
Manufacture Name  0 0 0 0 0 0 0 0
UID Number  UID  0 0 0 0 0 0
LAN Device  LAN  0 0 0 0 0 0 0 0

```

■ Main Menu

- Information - [Main] - Advanced - Security - Boot - Exit -

SystemTime:	[xx:xx:xx]
SystemDate:	[xx/xx/xxxx]
Boot Display	[Both]
Screen Expansion	[Disabled]
QuickBoot Mode:	[Enabled]
Startup Screen	[Disabled]
Boot on LAN	[Disabled]
Hotkey Beep	[Enabled]
Auto Dim	[Enabled]
F12 Multi-Boot	[Enabled]

[Main Menu](#)

Main Menu	BIOS default	BIOS value
SystemTime		XX:XX:XX [] 00 [] 23 [] 00 [] 59 [] 00 [] 59 []
System Date		XX/ XX/ XXXX [] 01 [] 12 [] 01 [] 31 [] 00 [] 00 []
Boot Display	Both	Auto
Screen Expansion	Disabled	Enabled
QuickBoot Mode	Enabled	Disabled
Statup Screen	Disabled	Enabled
Boot on LAN	Disabled	Enabled
Hotkey Beep	Enabled	Disabled
Auto Dim	Enabled	Disabled
F12 Multi-Boot	Enabled	Disabled

[illegible]

■ Advanced Menu ☒ ☐ ☐ ☐ ☐ ☐ ☐

```

- Information - Main - [Advanced] - Security - Boot - Exit -
Legacy Diskette A: [ 1.44/ 1.25MB 3 1/2" ]

▼ Primary Master [ C25ND20ATCS04-0- ]
▼ Secondary Master [ None ]

▼ Onboard Device Configuration

Wake on LAN from S5 [ Enabled ]
Reset Configuration Data: [ No ]

CPU Power Management Mode [ Auto ]

Embedded Shared Memory [ 16MB ]

```

Advanced Menu		
	BIOS default	BIOS value
Legacy Diskette A:	1.44/ 1.25MB 3 1/ 2"	Disabled
Primary Master		[IC25N020ATCS04-0-]
Secondary Master		None
OnBoard Device Configuration		
Wake on LAN from S5	Enabled	Disabled
Reset Configuration Data:	No	Yes
CPU Power Management Mode	Auto	Disabled
Embedded Share Memory	16M	32M

[illegible]

■ IDE Primary Master Information □ HDD □ □ □ □ □ □

```
-[Advanced]-
----- Primary Master [xxxxx]-----

Type:                                [Auto]

Multi-Sector Transfers:              [16 Sectors]
LBA Mode Control:                    [Enabled]
32 Bit I/O                           [Disabled]
Transfer Mode:                        [Fast PIO4]
Ultra DMA Mode:                       [Mode 5]
```

Primary Master Information		BIOS default	BIOS value
Type	Auto	Auto	
Multi-Sector Transfers			
LBA Mode Control			
32 BIT I/O			□ □ □ □ □ □ □ □
Transfer Mode			
Ultra DMA Mode			

Type Primary Master Auto

Multi-Sector Transfers

LBA Mode Control

32 Bit I/O

Transfer Mode

Ultra DMA Mode

■ IDE Secondary Master Information □ □ □ □ □ □ □ □ □ □

```

-[Advanced]-
----- Secondary Master [xxxxx]-----
Type:                               [Auto]

Multi-Sector Transfers:             [Disable]
LBA Mode Control:                   [Disable]
32 Bit I/O                          [Disable]
Transfer Mode:                      [Fast PIO 4]
Ultra DMA Mode:                     [Mode 2]

```

Secondary Master Information		BIOS default	BIOS value
Type	Auto	Auto	
Multi-Sector Transfers			
LBA Mode Control			
32 Bit I/O			□ □ □ □ □ □ □ □
Transfer Mode			
Ultra DMA Mode			

[illegible]

■ Onboard Devices Configuration Menu

- [Advanced]-

----- OnBoard Device Configuration -----

Serial Port: [Enabled]
Base I/O Address: [3F8]
Interrupt: [IRQ 4]

Parallel Port: [Enabled]
Mode: [Bi-directional]
Base I/O Address: [378]
Interrupt: [IRQ 7]

Onboard Devices Configuration Menu

	BIOS default	BIOS value
Serial Port	Enabled	Disabled
Base I/O Address	3F8	2F8/ 3E8/ 2EB
Interrupt	IRQ 4	IRQ 3
Parallel Port	Enabled	Disabled
Mode	Bi-directional	ECP/ Output only
Base I/O Address	378	278/ 3BC
Interrupt	IRQ 7	IRQ 5

Serial Port: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Base I/O Address: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Interrupt: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Parallel Port: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Mode: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Base I/O Address: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Interrupt: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

■ Security Menu

- Information - Main - Advanced - [Security] - Boot - Exit -

Set Supervisor Password [Enter]
Set User Password [Enter]

Password on boot: [Disabled]

Set Primary Hard Disk Password [Enter]

- I/O Security

USB [Enabled]
Audio [Enabled]
Modem [Enabled]
Serial Port [Enabled]
Parallel Port [Enabled]
Legacy Diskette A: [Enabled]

Security Menu

	BIOS default	BIOS value
Set Supervisor Password		Enter
Set User Password		Enter
Password on boot	Disabled	Enabled
Set Primary Hard Disk Password		Enter
USB	Enabled	Disabled
Audio	Enabled	Disabled
Modem	Enabled	Disabled
Serial Port	Enabled	Disabled
Parallel Port	Enabled	Disabled
Legacy Diskette A	Enabled	Disabled

Set Supervisor Password: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Set User Password: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

☐ ☐ [Supervisor Password] ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

☐ ☐ [User Password] ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

System Time/ System Date/ Boot Display/ Screen Expansion/ User Password
/ Exit Saving Changes/ Exit Discarding Changes/ Discard Changes/ Save Changes

Password on boot: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

☐ ☐ [Supervisor Password] ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Set Primary Hard Disk Password: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

USB: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Audio: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Modem: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Serial Port: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Parallel Port: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Legacy Diskette A: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

■ Boot Menu

- Information - Main - Advanced - Security - [Boot] - Exit -

Boot Priority from SS [Normal]

▼ Boot Sequence

Boot Menu

	BIOS default	BIOS value
Boot Priority from SS	Normal	LAN
Boot Sequence		[Boot Sequence] <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>

Boot Priority from SS: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

[Normal: Boot Sequence] ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

[LAN: SS] ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Boot Sequence: [Boot Sequence] ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

■ Boot Sequence ()

<p>----- [Boot] -----</p> <p>Boot Sequence -----</p> <p>#Renovable Devices</p> <p>CD ROM Drive</p> <p>#Hard Drive</p>

Removable Devices
CD-ROM Drive
Hard Drive

■ Exit Menu () () () () ()

```
- Information - Main - Advanced - Security - Boot -[Exit]-
Exit Saving Changes
Exit Discarding Changes
Load Setup Defaults
Discard Changes
Save Changes
```

Exit Saving Changes

Exit Discarding Changes

Load Setup Defaults

Discard Changes

Save Changes